

Chain holder if there is slope or soft ground

All models of RH-Pusher/TreeJack will be equipped with a chain holder from our production start July 2024. Some tools already have it welded on.

Facts:

The groove in chain holder fits a chain with links up to 7 mm thickness, minimum chain length should be 3,5 meters.

Attach the chain around the tree, pull the chain under the footplate of the TreeJack, push the chain in the groove, the length of the chain depends on the slope of the ground.

By using a piece of wood stops the tool to sink in the ground.

If you own a tool without chain holder there is a possibility to buy it separately and either weld it on or screw it in the footplate with bolts and locking nuts, these are included (you need to drill 2 holes 9 mm in the footplate).



Manufactured by:



Box 183, 243 23 Höör, Sweden
Tel: 0413-249 48